

DESCRIPTION OF THE P35 CORKING MACHINE

Our P35 corking machine meets the requirements of those wine-growers who need a rapid and precise corking.

Our P35 corking machine is almost entirely made of stainless steel to make cleaning easier. Moreover all those parts which could come into contact with the corks are made of materials that do not react with the air (such as stainless steel, plexiglass, chromium-plated steel), in order to prevent all chances of polluting corks with rust splinters or whatever other substances bad for health. Even the internal mechanisms, such as connecting rods and levers, are galvanized. All the parts which come into contact with the bottle are made either of rubber or pvc to avoid the breaking off of splinters from the glass.

The mechanisms that must bear heavier loads are supported by ball-recirculating or roller-recirculating elements in order to guarantee both a higher precision of functioning and a higher resistance to wear.

All moving gears are protected by safety guards and those parts which the operator must reach often, such as the cork container and the jaws, are fitted up with easily removable safety guards. The latter are equipped with a sensor so that the corking machine cannot work when these guards are removed.

SAFETY SYMBOLS:



General danger



Caution: refer to the operator's handbook



ndbook - P35 corking machine

Caution: 230 Volt tension.




Caution: rotating gears. Severing of fingers.

OPERATING DIRECTIONS

Our P35 corking machine is provided with an upper cork container which is fitted up with a mechanical mixing device that lines the corks up and pushes them through the descent duct for the corking to be carried out successfully. This corking machine positions the cork within jaws which squeeze it down to the size of the neck of the bottle. In this way less stress is needed to push the cork down into the neck of the bottle with the advantage of not damaging the cork itself that will expand once it is inserted and ensure a good seal.

To start the corking machine a bottle must be placed on the bottle platform, **the two starting push-buttons located on the sides of the machine must be kept pressed simultaneously for a couple of seconds** (see picture 1). In this way the working cycle starts off: the bottle platform goes up, the jaws go down and compress the cork which is afterwards inserted into the neck of the bottle by the cork-pushing pin (see picture 1).

At this point the two push-buttons can be released to start the cycle of return off. This means the lowering of the bottle platform, the ascent of the cork-pushing pin and the rotation of the cork pusher which picks up a cork from the cork descent duct and drives it into the jaws ready to be used next time.



Picture 1.

TECHNICAL DETAILS

Standard equipment:

- cork size diameter 22-26 x 50 mm.
- bottle height up to 390 mm.
- corking time approximately 1,8 seconds

Optional equipment:

- cork descent duct and cork pusher for corks with diameter up to 28 mm.

P35 corking machine

Height: 1810 mm.

Width: 520 mm.

Length: 560 mm.

Weight: 126 kg.

Mono-phase motor:

Feeding: 110 Volt, 60 Hz

Speed rotation: 1380 r.p.m.


Power: 0,75 Kw

Screw reducer without end:

reduction ratio 1/40

INSTRUCTIONS FOR USE


- Positioning. The P35 corking machine should be placed on an even ground.
Make sure that the screws which hold the safety guards are screwed tight, especially those which hold the switch-board.
- Clean all the parts that come into contact with the corks, such as the cork descent duct, cork pusher, jaws, cork-pushing pin and cork container (see picture 1).
- Check that no foreign matters which could compromise the good functioning of the machine are either inside the cork container or inside the jaws.
- Take off the antiscratch blue nylon film from the front plastic safety guard, tighten the fasteners and make sure the pin can activate the safety sensor (for the sensor of the jaws and the plastic pin of the safety guard, see picture 2).
- Adjust the height of the bottle platform by undoing the two bolts (see picture 2) which hold it tight, then re-tighten the bolts so that the top of the bottle is near the bottle-height line underneath the jaws.




Picture 2.

Fill up the cork container and close the lid. When the lid is open, the respective sensor is not operated (see picture 3) and the corking machine cannot start.

Connect the feeding cable to a 110 volt current-tap, turn clockwise the quick-stop button of the switch-board and turn the starting switch to position 1 (see picture 4). Now a green light should be lit and the corking machine can be started by pressing the two starting push-buttons located on the sides of it (see picture 1).



Picture 3.



Picture 4.

CAUTION

The corking machine can be used by only an operator at a time and no one else should be near when the feeding cable is connected and the corking machine is operating.


In order to prevent any accident the two starting push-buttons must be kept pressed and both hands must be kept in this position until the corking operation has been carried out.

VACUUM / AZOTE

To suck up the air and obtain some depression between the cork and the wine, it is enough to turn the vacuum / azote switch until the green vacuum indicator lights up (see picture 4). By just pressing the starting push-buttons, it is possible to get both the bottles corked and some depression inside them. The depression is obtained by creating vacuum inside a tank by means of a pump and putting in transmission this tank with the bottle during the last part of the corking operation, that is when the bottle is in its upper position and is about to be corked. The vacuum level inside the tank is visualized on the vacuumeter and it is adjustable through the special knob (see picture 5: vacuum regulator). The vacuum level is proportional to the depression inside the corked bottle. It

is advisable to keep the vacuumeter on a value between -0,7 / -0,9 for corks and on a value between -0,6 / -0,8 for synthetic stoppers. Once the bottle is corked the depression inside the bottle can reach -0,4 bar compared to the atmospheric pressure.

Otherwise if you want to put in azote before the corking, connect the azote feeding hose to the special connection (see picture 5). Then turn the azote / vacuum switch to light the green azote indicator (see picture 4). In this case, the pressure can be adjusted through the regulator located on the azote bottle. It is advisable not to set values too high, such as 0,3 bar above the atmospheric pressure.



Picture 5.

CAUTION

It is important to check the oil level of the air-pump before starting work. The oil level of the pump can be checked through a round indicator that can be seen through the fissures of the wheeled support (see picture 5: oil level of the pump); in order to obtain proper functioning, the oil level inside this indicator must be at about half-way.

The oil level has to be checked at least every 20 working hours.


FAULTS AND REMEDIES CHECK LIST

- When the machine is operating the green light (see picture 4) must be on. If it is not so, you must check that the pin of the plastic front guard starts the respective sensor in the correct way and the lid of the cork container is closed.
- It should be noted that once the quick stop push-button is pressed, it stays pressed and in order to release it, it must be turned clockwise. For this reason, if the machine doesn't start, it may have been pressed the push-button by mistake; in this case, turn it and try again.
- If one tries to remove the plastic guard or to open the lid, the green light goes off, the machine stops immediately and the bottle-stand remains half-way of its stroke. In order to bring the bottle-stand to its starting position, one must relocate the guards or the lid and press the starting push-buttons.

IMPORTANT

Before intervening on the machine always bring the starting switch back to the "0" position and disconnect the feeding cable.

- If at the end of the corking operation the bottle-stand doesn't go to the lower position of its stroke, open the left side of the machine (it is meant left being in front of the machine). Loosen the grain of the end-of-stroke-element (see picture 5) and try to turn it; if one turns it clockwise the end of the corking cycle is anticipated (the bottle-stand reaches its lower point and tends to go up), if you turn it anti-clockwise the end of the corking cycle is delayed (the bottle-stand doesn't reach its lower point). Re-tighten the side down and re-start the machine.



Picture 6.

- If the corks don't go down the cork descent duct correctly open the lid of the cork container and mix the corks.

- In case the corks are not picked up precisely by the cork pusher, it is necessary to adjust the stroke of the cork pusher itself (the cork pusher is fastened to the upper plate of the jaws) (see picture 6: screws of the jaws). To do this, the six upper screws of the jaws must be loosened and the upper plate of the jaws can be moved towards the corking machine or in the opposite direction. Tighten the screws and start the machine; if the result is not satisfying, repeat the operation.


- If it is needed the cork to be inserted deeper or higher in the neck of the bottle, the fastening nut must be loosened and the cork-pushing pin turned: the last is threaded then it can be moved up and down. Before starting the machine again, the fastening nut must be tightened (see picture 6).

In case one does not succeed in carrying out the above mentioned adjustment (especially it could not be successful with synthetic stoppers) it is advisable to adjust the tightening of the jaws.

Our P35 corking machine is set to compress the corks to a diameter of 16 mm.

- When the jaws are tightened and the cork-pushing pin starts to push a cork down, it may happen that the bottle-stand cannot keep its position and tends to go down so that it doesn't allow the cork to be fully inserted. In this case it is the ascent system of the bottle stand that needs maintenance. It is necessary to remove the bottle stand by loosening the bolts; the mobile guard plates and the lower guard plate must be removed too (see picture 7): the cylindrical rod on which the bottle stand moves up and down must be cleaned (see picture 7). It is advisable to use a dry cloth and rub vigorously to remove whatever dust. Then it's a good rule to lubricate the cylindrical rod with a drop of oil (and not more, one should never exaggerate with the lubrication). In case the machine vibrates a little, one should lubricate the inside of the jaws and let the machine do a couple of blank strokes. Before starting work it is better to clean the jaws to prevent the oil from dirtying the corks (see picture 1).

If the vibrations continue it is advisable to loosen the bolts of the back guard (reference 108 on the table "Components of the P35 corking machine") and lubricate all the pins and bearings inside. In case the problem persists turn to the manufacturer.



Picture 6.

CAUTION

In the event of strong vibrations of the machine immediately push the quick-stop push-button and contact the local dealer.

MAINTENANCE



A long machine working life is dependent upon constant and methodical compliance with the following instructions:

- take off the back plate (reference 108 on the table "Components of the P35 corking machine") and lubricate the bearings, the slide and the pins inside the machine;
- clean the jaws from any cork dust;
- lubricate the inside of the jaws and remove the excess oil before starting work.


At the end of each season we recommend to:

- carefully clean the machine and the jaws;
- store the machine in a dry place and cover it up with a cloth or a nylon film in order to prevent the dust from crusting over the corking machine.

ELECTRIC SYSTEM



ELECTRIC SYSTEM FOR VACUUM




| POS. | DESCRIPTION | REF. | POS. | DESCRIPTION | REF. |
|------|------------------------------|---------|------|--------------------------------|-----------|
| 1 | 0,75 KW motor | tap0201 | 35 | Base | tap1028 |
| 2 | Reducer | tap0202 | 36 | Push-button sensor | tap0225 |
| 3 | Flange | tap0203 | 37 | M4x30 screw | tap0309 |
| 4 | Motor guard | tap1317 | 38 | Support | tap0502 |
| 5 | Right side plate | tap1301 | 39 | 10 mm. diam. pin | tap1024 |
| 6 | M10x25 screw | tap0301 | 40 | M10 washer | tap0310 |
| 7 | M8x16 screw | tap0302 | 41 | 10 mm. diam. elastic ring | tap0210 |
| 8 | Washer | tap0303 | 42 | Cork-pushing pin | tap1315 |
| 9 | M10 nut | tap0304 | 43 | M18 nut | tap0326 |
| 10 | SBPF 205 support | tap0204 | 44 | Connection | tap1313 |
| 11 | 8x7x40 tongue | tap0205 | 45 | Side plates | tap1312 |
| 12 | Cam shaft | tap1031 | 46 | M12 nut | tap0311 |
| 13 | HK 6020 roller-shell | tap0206 | 47 | Upper safety guard | tap1319 |
| 14 | Engine connecting rod | tap1005 | 48 | Connection | tap1043 |
| 15 | 60 mm. diam. elastic ring | tap0207 | 49 | Lever | tap1304 |
| 16 | Spring | tap0011 | 50 | Connecting rod | tap1336 |
| 17 | M8x30 cylindrical head screw | tap0305 | 51 | 15 mm. diam. pin | tap1023_2 |
| 18 | M8 nut | tap0306 | 52 | 15 mm. diam. elastic ring | tap0211 |
| 19 | M6 threaded pin | tap0513 | 53 | Spacer | tap1007 |
| 20 | Connecting rod | tap1308 | 54 | 18 mm. diam. pin | tap1003 |
| 21 | Reference for bottle | tap0508 | 55 | Spacer | tap1322 |
| 22 | M10 washer | tap0307 | 56 | Spacer | tap1323 |
| 23 | Connection | tap0505 | 57 | 15 mm. diam. pin - short model | tap1023_1 |
| 24 | Brake | tap0506 | 58 | Spacer | tap1329 |
| 25 | Brake connecting rod | tap0507 | 59 | 15 mm. diam. pin - long model | tap1324 |
| 26 | Bottle platform-holder | tap0504 | 60 | Pin | tap1325 |
| 27 | Handgrip with M8x16 screw | tap0208 | 61 | Connecting rod | tap1307 |
| 28 | Spring | tap0006 | 62 | Lever | tap1305 |
| 29 | Bottle platform | tap0509 | 63 | Cork descent duct | tap1213 |
| 30 | M8x20 screw | tap0308 | 64 | Connection | tap0213 |
| 31 | Back plate | tap1032 | 65 | Slide | tap1211 |
| 32 | Threaded spacer | tap1036 | 66 | SBPF 203 support | tap0214 |
| 33 | Front plate | tap1025 | 67 | Right side plate | tap1214 |
| 34 | Cylindrical rod | tap0501 | 68 | Tongue | tap1210 |

| POS. | DESCRIPTION | REF. |
|------|------------------------------|---------|
| 69 | Spring | tap0008 |
| 70 | Spacer | tap1212 |
| 71 | Left side plate | tap1215 |
| 72 | Shaft | tap1209 |
| 73 | Cork container | tap1201 |
| 74 | Pinion | tap0215 |
| 75 | Threaded handgrip | tap0216 |
| 76 | Left flank | tap1302 |
| 77 | Sensor | tap0217 |
| 78 | Sensor guard | tap0218 |
| 79 | SKF 4302 bearing | tap0226 |
| 80 | Sensor support | tap1018 |
| 81 | M6x20 cylindrical head screw | tap0312 |
| 82 | SBPF 204 support | tap0219 |
| 83 | End of stroke cam | tap1019 |
| 84 | Spacer | tap1029 |
| 85 | Pinion | tap0220 |
| 86 | 8 mm. - pitch chain | tap0221 |
| 87 | Chain guard | tap1316 |
| 88 | Connection | tap1337 |
| 89 | Push-buttons | tap0227 |
| 90 | Plaastic guard | tap0714 |
| 91 | Spring | tap0007 |
| 92 | Cork pusher | tap0801 |
| 93 | SKF 625-2Z bearing | tap0228 |
| 94 | M8x16 cylindrical head screw | tap0313 |
| 95 | Upper plate | tap0709 |
| 96 | Fork | tap0702 |
| 97 | Prism for jaws | tap0701 |
| 98 | Spring-loaded angle bar | tap0705 |
| 99 | Threaded angle bar | tap0704 |
| 100 | Side plate | tap0706 |
| 101 | Lower mobile guard | tap0512 |
| 102 | Lower plate | tap0708 |

| POS. | DESCRIPTION | REF. |
|------|-------------------------------|---------|
| 103 | Spring | tap0004 |
| 104 | Cone | tap0713 |
| 105 | Block | tap0719 |
| 106 | Lower safety guard | tap1320 |
| 107 | Mobile upper safety guard | tap0510 |
| 108 | Back safety guard | tap1321 |
| 109 | M4x10 cylindrical head screw | tap0327 |
| 110 | M8x20 cylindrical head screw | tap0334 |
| 111 | M5x45 cylindrical head screw | tap0315 |
| 112 | M5 nut | tap0316 |
| 113 | M8x10 screw without head | tap0317 |
| 114 | M4x6 countersunk head screw | tap0336 |
| 115 | M5x30 screw | tap0319 |
| 116 | M10x20 cylindrical head screw | tap0328 |
| 117 | M6 nut | tap0321 |
| 118 | 5x30 elastic pin | tap0224 |
| 119 | M4 nut | tap0329 |
| 120 | M8x8 countersunk head screw | tap0322 |
| 121 | M6x25 screw | tap0335 |
| 122 | Electric panel | |
| 123 | M6x12 screw | tap0324 |
| 124 | M4x16 countersunk head screw | tap0325 |
| 125 | Washer for M16 screw | tap0330 |
| 126 | M5x20 cylindrical head screw | tap0331 |
| 127 | Spacer | tap0716 |
| 128 | M6x8 screw without head | tap0332 |
| 129 | M5x12 countersunk head screw | tap0333 |
| 130 | Fork | tap1310 |
| 131 | Moving part | tap0229 |
| 132 | Slide | tap0230 |
| 133 | Wedge | tap1309 |
| 134 | Plate | tap1314 |
| 135 | Bushing | tap0514 |
| 136 | M18 threaded bar | tap0231 |

COMPONENTS OF THE P35 CORKING MACHINE


COMPONENTS OF THE WHEELED SUPPORT













| POS. | DESCRIPTION | REF. |
|------|------------------------|-----------|
| 1 | Frame | tap1330 |
| 2 | Back plate | tap1332-1 |
| 3 | Front plate | tap1332 |
| 4 | M6x25 stainless screws | tap0347 |
| 5 | Washer for M6 screw | tap0330 |
| 6 | M8x16 stainless screw | tap0302 |
| 7 | Air-pump | tap0232 |

| POS. | DESCRIPTION | REF. |
|------|-------------------------|---------|
| 8 | Vacuum tank | tap0233 |
| 9 | M12 nut | tap0346 |
| 10 | Washer for M2 screw | tap0345 |
| 11 | M12x35 screw | tap0344 |
| 12 | Plastic wheel | tap0238 |
| 13 | Valve 1/2 for gas | tap0239 |
| 14 | Stainless steel M6 nut | tap0321 |
| 15 | Tank connection surface | tap1331 |

Components of the P3 corking machine



Electric system



Electric system for vacuum

