



DIRECTIONS:

Wrap each stainless fitting with 5 wraps of PTFE Thread Sealant Tape (included) in a clockwise direction. The nipple should be wrapped on both sides. Install fittings in the order shown and tighten with a wrench.

