

ASSEMBLY INSTRUCTIONS FOR HOP BONG PRESSURE PACK

1. Assemble the hop bong as shown - **Photo 1**
2. Release all pressure from your conical - **Photo 2**
3. Attach hop bong to 1.5" TC port - **Photo 3**
4. Close valve - **Photo 4**
5. Fill with hops - **Photo 5**
6. Flush with gas and pull on ring to release CO₂ - **Photo 6**
7. Open the valve and allow hops to enter conical - **Photo 7**
8. With the valve open, pull the relief valve to release any pressure - **Photo 8**
9. Remove hop bong

