

Brewmaster

OxyWand™ Oxygenation System



Kit Includes:

- 0.5 Micron OxyWand™
- Oxygen Regulator
- Sanitary Air Filter
- Tubing

You will also need:

Small disposable oxygen tank
from the hardware store.

OxyWand™ Oxygenation System

How do I use my system?

1. Sanitize the OxyWand™ and tube. (See below for more details)
2. Insert the OxyWand™ down to the bottom to the fermenter.
3. Turn the knob on top of the regulator until you see bubbles coming from the stone.
4. Total time of oxygenation should be about 1 to 2 minutes, depending on the gravity of your wort. Remove your OxyWand™ and install an airlock.
5. Clean & sanitize your OxyWand™ & store in a clean dry location.

Suggestions on cleaning and sanitizing: There are many effective methods for cleaning and sanitizing air stones. Our recommendation is to boil the stone for 2 minutes prior to use and then insert into your sanitizing solution. After use insert the stone back into your bucket of sanitizer and blow oxygen through for 5-10 seconds. Remove the stone and store dry.

Brewmaster
SINCE 1971

BrewmasterWholesale.com • 1-800-288-8922